



HI-VIS CONCRETE BALLAST BLOCK INSTALLATION GUIDE

The high visibility concrete ballast block is a great way to quickly add stability to your temporary fence system.



Equipment / Accessories Needed:
No accessories or tools required.



Erect the temporary fence system as usual.



To add the ballast, simply place the ballast block over the top of the rubber fence foot.



The ballast blocks are designed to stack neatly on top of each other.



Repeat steps 2 and 3 throughout on the fencing used.



