



CONCRETE JERSEY BARRIER INSTALLATION GUIDE

Jersey Barriers are designed to provide the ultimate anti-vehicle protection. Despite their heavy weight, these solid barriers are easy to install and require no additional fixtures and fittings.

People to Install:



Equipment / Accessories Needed:

- Specialist lifting equipment



1 Plan where you want the barriers to be positioned and position close to their final position using a specialist equipment (such as a telehandler).



2 Use forklift truck to position the barriers in the correct place. The distance between the forklift holes on each barrier is 600mm. Each forklift slot 180mm.



3 Fix your first barrier in position and butt the second barrier up to the first. The Jersey barriers are designed to interlock and fit together to form a tight join.